GRAVITY REEL TOE SWITCH by Joao Miranda

If you wish to control your Gravity Reel hands free and/or without the programming delay, you can choose to control it via a custom-designed Toe Switch.

The package includes an insole, a custom-designed switch with the proprietary male connector and several accessories.

It allows you to control one motor in LIVE MODE or to start a program.

(Instructions are in your original Gravity Reel instructional page)