
OneTouch 2 SnowShot (STAGE edition) with Remote control by Victor Voitko

DOUBLE OneTouch SnowShot is a fine gimmick that can be used on various occasions. Flash gun, confetti shooter, fireworks launcher are now in one device - **OneTouch SnowShot**.

Now two shots work simultaneously from one remote control. This doubles the effect. You can place these devices in different places in the scene.

With it, you can make plenty of confetti, a huge explosion flame, incredible fireworks or you can even make a handkerchief to appear from your device in any time of your show.

- 100% works
- Works without any pause and delay
- Easy to use
- Remote control
- Rechargeable battery
- One battery charge for more than 200 shots
- One shot - a huge amount of confetti
- Flash cotton only or flash cotton combined with sparkles or flash paper can be used

Specifications:

- Remote control
- Flash cotton usage
- Battery is rechargeable
- One charge - more than 200 shots

The **DOUBLE OneTouch SnowShot** set includes:

- 2 x special shot device
- 1 x remote control
- 2 x stand for device
- 1 x pack of confetti
- 1 x USB charger

NOTE:

Be careful using this device with flash cotton, flash paper, Fireworks or other inflammable items!

Do not direct this device toward your face, body or toward other people or animals!