
ONE TOUCH SNOW SHOT by Victor Voitko

OneTouch SnowShot (hand edition). Remote control.

OneTouch SnowShot is a fine gimmick that can be used on various occasions. Flash Gun, Confetti Shooter, Fireworks Launcher are now in one device - **OneTouch SnowShot**.

With it, you can make plenty of confetti, a huge explosion flame, incredible fireworks or you can even make a handkerchief to appear from your device in any time of your show. You can put it in any place of a stage.

- 100% works
- Works without any pause and delay
- Easy to use
- Rechargeable battery
- One battery charge for more than 200 shots
- One shot - a huge amount of confetti
- Flash Cotton only or Flash Cotton combined with sparkles or Flash Paper can be used

Specifications:

- Flash cotton usage
- Battery is rechargeable
- One charge - more than 200 shots

The OneTouch SnowShot set includes:

- 1 x Special Shot Device
- 1 x Holder on the hand
- 1 x Remote control
- 1 x Pack of Confetti
- 1 x USB Charger